



User Manual Shower

Manual de Uso Ducha

EN

The shower has two controls. The top knob controls the water outlet, allowing you to choose between the overhead shower or the handheld showerhead. The bottom knob controls the temperature in degrees Celsius. These knobs do not control the water pressure, as it is automatically regulated when the shower is turned on.

ESP

La ducha cuenta con dos mandos. El de arriba controla la salida de agua de la ducha, ya sea desde el techo o bien por la ducha de mano. Mientras que el de abajo controla la temperatura en grados C°. Estos mandos no controlan la presión, la cual es automática al encender la ducha.