



User Manual A/C

Manual de Uso Aire Acondicionado

EN

The air conditioning system operates using the remote control. The apartment is equipped with an energy-saving system, so if an open window is detected, the mini-split will automatically turn off.

How to use:

1. Press ON/OFF to turn the unit on or off.
2. Use the MODE button on the remote control to select between:
 - Cool - for cooling
 - Heat - for heating
 - Fan - circulates air without heating or cooling
 - Dry - reduces humidity without significantly lowering the temperature
 - Auto - detects the room temperature and adjusts the mode automatically

The recommended comfort temperature is 23.5°C / 74.3°F.

[View the complete user manual here:](#)

ESP

El sistema de aire acondicionado funciona utilizando el control remoto. El apartamento está equipado con un sistema de ahorro de energía, por lo cual si se detecta una ventana abierta apagará de forma automática el funcionamiento del mini split.

Modo de uso:

- Presione ON/OFF para encender o apagar.
- Con el botón MODE en el control remoto puedes elegir entre:
 - Frío (cool)
 - Calor (heat)
 - Ventilación (fan) solo mueve aire sin calentar o enfriar
 - Deshumidificador (dry) Reduce la humedad sin bajar mucho la temperatura.
 - Automático (auto) Detecta la temperatura y ajusta el modo automáticamente.

[Consulta aquí el manual completo aquí](#)