




User Manual Safe Deposit Box

Manual de Uso Caja de Seguridad

EN

To use the safe, first program your unique user passcode.

With the door open, locate the programming button on the inside of the door, press it to begin changing the code, enter the new user code, and confirm.

When you close the door, make sure the latch retracts and the door is securely closed.

To open the safe, enter the programmed code on the electronic keypad and press the “#” or “Enter” button to open the door.

ESP

Para utilizar de la caja fuerte primero debes de programar tu contraseña única de uso.

Con la puerta abierta localiza el botón de programación en el interior de la puerta, pulsa para iniciar el cambio de código, introduce el nuevo código de usuario y confirma.

Cuando cierres la puerta asegúrate que el pestillo se retraiga y la puerta haya quedado bien cerrada.

Para abrir la caja introduce la clave proramada en teclado electrónico y presiona el botón “#” o “Enter” para abrir la puerta.