




User Manual Microwave

Manual de Uso Microondas

EN

The microwave includes defrosting, heating, and cooking functions by time and food type, as well as the option to select the heating power with 5 different levels and grill power to brown or gratinate food with 3 power levels.

Usage recommendations:

Always use a microwave-safe plastic cover when cooking food.

For the grill function, do not place anything on top of the dish so that the grill elements can properly brown the food.

[View the complete user manual here](#)

ESP

El microondas incluye la función de descongelación, calentamiento y cocinado por tiempo y tipo de alimento, así como la posibilidad de seleccionar la potencia de calentamiento con 5 niveles diferentes y la potencia del grill para poder gratinar alimentos con 3 niveles de potencia.

Recomendaciones de uso:

Procura siempre colocar una tapa plástica apta para microondas para cocinar alimentos.

Para la función de grill no se debe de colocar nada encima del platillo para que las resistencias del grill puedan gratinar.

[Consulta aquí el manual completo aquí](#)