



User Manual Toaster

Manual de Uso Tostadora

EN

Two-Slot Bread Toaster with wide slots for medium-sized slices of bread. It features 6 different browning levels and three pre-programmed functions: defrost, reheat, and a cancel button to stop toasting at any time and achieve the desired level.

It includes a crumb tray, which is recommended to be emptied and cleaned after each use.

[View the complete user manual here](#)

ESP

Tostadora de pan con 2 ranuras anchas para rebanadas de pan medianas. Tiene 6 niveles diferentes de tostado y cuenta con tres funciones preprogramadas: descongelar, recalentar y el botón de cancelar el tostado en cualquier momento para alcanzar el nivel de tostado deseado.

Cuenta con una bandeja recogemigas que se recomienda vaciar y limpiar después de cada uso.

[Consulta aquí el manual completo aquí](#)